

# DARMOSHARK K7 GAMING KEYBOARD QUICK START GUIDE

运营商: 香港飞翔科技集团有限公司  
 制造商: 深圳市宝安区智源电子厂 地址: 深圳市宝安区沙井南浦路  
 Operator: Motospeed Technology Group Limited  
 Manufacturer: Mototech Technology Group Limited  
 Address: Nanpu Road, Shajing, Bao'an Shenzhen P.R. China  
 HOTLINE: 4008-860-368  
 以上数据仅供参考, 实物与图片可能不相符!  
 最终解释权归本公司所有  
**WWW.DARMOSHARK.CN**



FN+F1=screen brightness reduction  
 FN+F2=screen brightness increase  
 FN+F3=Multi-screen display  
 FN+F4=Main control panel  
 FN+F5=Resource manager  
 FN+F6=Volume reduction  
 FN+F7=Volume up  
 FN+F8=mute  
 FN+F9=Play/Pause  
 FN+F10=Stop  
 FN+F11=Previous song  
 FN+F12=Next song

FN+ESC=Restore factory settings  
 FN+WIN=lock/unlock WIN  
 FN+\|=Light recording  
 FN+[]=PRINT  
 FN+]=PAUSE  
 FN+;|=HOME  
 FN+'|=END

FN+DEL=light effect mode (14 types)  
 FN+PGUP=light effect direction (individual)  
 FN+INS=Light effect monochrome  
 FN + up and down arrow keys = five levels of brightness  
 FN + left and right arrow keys = five levels of speed

## SYSTEM REQUIREMENTS:

Windows XP/WIN7/WIN8/ WIN10/VISTA  
 IBM or compatible computer

FN+F1=屏幕亮度减  
 FN+F2=屏幕亮度加  
 FN+F3=多屏显示  
 FN+F4=主控面板  
 FN+F5=资源管理器  
 FN+F6=音量减  
 FN+F7=音量加  
 FN+F8=静音  
 FN+F9=播放/暂停  
 FN+F10=停止  
 FN+F11=上一曲  
 FN+F12=下一曲

FN+ESC=恢复出厂设置  
 FN+WIN=锁/解锁WIN  
 FN+\|=灯光录制  
 FN+[]=PRINT  
 FN+]=PAUSE  
 FN+;|=HOME  
 FN+'|=END

FN+DEL=灯效模式切换(14种)  
 FN+PGUP=灯效方向切换(个别模式)  
 FN+INS=灯效单色切换  
 FN+上下方向键=五级亮度调节  
 FN+左右方向键=五级速度调节

## 系统要求

Windows XP/WIN7/WIN8/ WIN10/VISTA  
 IBM或兼容计算机

中文  
 尺寸:385X132X43MM  
 重量:963g  
 寿命:50,000,000times(次)  
 数量:98键

Türk dili  
 Boyut: 385X132X43MM  
 Ağırlık: 963g  
 Hayat: 50.000.000 kez (kez)  
 Miktar: 98 tuş

Ελληνικά  
 Μέγεθος: 385X132X43MM  
 Βάρος: 963g  
 Ζωή: 50.000.000 φορές (φορές)  
 Ποσότητα: 98 κλειδιά

English  
 Size: 385X132X43MM  
 Weight: 963g  
 Life: 50,000,000times (times)  
 Quantity: 98 keys

Português  
 Tamanho: 385X132X43MM  
 Peso: 963g  
 Vida: 50.000.000 vezes (vezes)  
 Quantidade: 98 chaves

Deutsch  
 Größe: 385X132X43MM  
 Gewicht: 963g  
 Leben: 50.000.000mal (mal)  
 Menge: 98 Schlüssel

Español  
 Tamaño: 385X132X43MM  
 Peso: 963g  
 Vida: 50,000,000 veces (veces)  
 Cantidad: 98 llaves

Українська  
 Розмір: 385X132X43MM  
 Вага: 963 г  
 Життя: 50 000 000 разів (рази)  
 Кількість: 98 ключів

## 自定义灯光录制

任意模式下, 按FN+\|进行自定义灯光颜色录制, 此时指示LED闪烁, 需要先单独按下其中(U/I/O/P)键进行选择, 指示LED停止闪烁, 再任意按下按键, 可选择8种颜色及无光循环切换, 直到自己喜欢的颜色, 最后按下FN+\|保存, 录制成功。(进入录制后检测到10秒没有任何按键被按下自动保存退出)

FN+U/I/O/P

## CUSTOM LIGHT RECORDING

In any mode, press FN+\| to record the custom light color. At this time, the indicator LED is flashing, you need to press the (U/I/O/P) button to select, the indicator LED stops flashing, and then press the button arbitrarily, Can choose 8 colors and matte cycle switch, until you like the color, finally press FN+\| to save, the recording is successful. (After entering the recording, it is detected that no buttons are pressed for 10 seconds, automatically save and exit)

FN+U/I/O/P